

How to Install CUPS Driver
(ESC/POS for ARM11)

SEWOO Thermal Printer

1. ARM based Linux

1.1. Installation.

1. Extract this archive creating the `sewoocupsinstall_arm` directory automatically.

```
# tar -zxvf sewoocupsinstall_arm.tar.gz
```

2. Open your favorite shell (bash, etc.) and move to the `sewoocupsinstall_arm` directory.

```
# cd sewoocupsinstall_arm
```

3. Execute the 'su' command to obtain super-user level permissions.

You must enter the root user's password for this to succeed. Be careful!

4. Type 'make install' to install this package onto your computer.

```
# make install [Enter]
```

Or

```
> sudo sh setup.sh [Enter]
```

A successful install should result in output similar to this:

```
# installing
cp ppd/*.gz install
cd install; exec ./setup
SEWOO TECH
SEWOO TECH CUPS Driver 1.0.0 installation Start
-----
```

Models included:

SEWOO LKT Series

Searching for ServerRoot, ServerBin, and DataDir tags in /etc/cups/cupsd.conf

ServerBin tag is present as an absolute path

DataDir tag is present as an absolute path

ServerRoot = /etc/cups

ServerBin = /usr/lib/cups

DataDir = /usr/share/cups

Copying rastertosewoo filter to //usr/lib/cups/filter

Copying Model PPD files to //usr/share/cups/model/SEWOO

Restarting CUPS

cups: stopped scheduler.

cups: started scheduler.

Install Complete

Add printer queue using K Menu -> Utilities -> Printing -> Printing Manager, or

Add printer queue using OS tool, <http://localhost:631>, or <http://127.0.0.1:631>

5. Goto <http://127.0.0.1:631> or use your favorite CUPS admin tool.

Or K Menu -> Utilities -> Printing -> Printing Manager.