

# VFD Utility All In One: MP Mode Command

## 1. Command List

P07303II\_AIO.exe [**/a or /p=PORT**] [/u=FILE\_PATH] [/c=FILE\_PATH] [/f=FILE\_PATH]  
[/v]

\* []: Necessary

\* []: Option

Parameter	Description
/a	Auto-scan serial port to find VFD device.  This parameter will take a while to scan device and can't use with "/p" the same time.
/p	Specify serial port to scan.  This parameter can't use with "/a" command the same time.  Ex: /p=COM1
/u	Update Firmware and specify ebin file path.  Ex: /u=c:/temp/test.ebin
/c	Configure VFD Device from file.  Ex: /c=C:/temp/Config/4CMVD00V0006.cfg
/f	Update user defined font from file.  Ex: /f=c:/temp/test.luf
/v	Verify the configuration and firmware version.  This parameter will confirm the settings. The settings include configuration and firmware version.
/q	Quit when the MP procedure finish.

## 2. Example:

The options have order by description above.

**EX:** P07303II\_AIO.exe /a /u=FW/VD00-025.ebin /c=Config/4CMVD00V0006.cfg  
/f=Config/03241.luf /v

The example above means steps below.

Step1: auto-scan	Step2: Update Firmware fromVD00-025.ebin
Step3: Setup configurations from 4CMVD00V0006.cfg	Step4: Update user defined font from 03241.luf
Step5: Verify Settings	

